


3900 Central Parkway
Hudsonville, MI 49426
toll free 800.338.7337
office 616.896.7100

techsupport@soundoffsignal.com
www.soundoffsignal.com



by SoundOff Signal

WINDSHIELD LIGHT ASSEMBLY INSTRUCTIONS EL3H04A0+(x)



WARNING: Warning devices are strictly regulated and governed by Federal, State and Municipal ordinances. These devices shall be used ONLY on approved vehicles. It is the sole responsibility of the user of these devices to ensure compliance.

MOUNTING INSTRUCTIONS

Important: DO NOT over tighten mounting screws or nuts. This could cause permanent damage to the unit. Use hardware supplied for mounting.

1. Assemble the UltraLITE as shown in the exploded illustration by inserting the carriage bolt in the channel on the back of the light.
2. Install the pivot block and the angular adjustment arm on the bolt and loosely secure with a nut.
3. Install the head adjustment arm as shown and lightly secure with nut.
4. Snap suction cups into place.
5. Press suction cups to windshield assuring that unit is not located where it obstructs the driver's vision or in the area of air-bag deployment.
6. Make sure the light is horizontal and carefully tighten all nuts.
7. Plug cigarette plug into receptacle and refer to operation instructions to activate light.

OPERATING INSTRUCTIONS

1. Plug the 12V adaptor into the appropriate receptacle.
2. Press the button for less than one second (momentary) to move forward one pattern.
3. Press and hold the button for one second (until the lights dim) to move backwards one pattern
4. Press and hold the button for more than two seconds (until the lights turn off) to turn off the UltraLITE.
5. To turn the unit back on, press the button again.

Input Voltage: 10-16Vdc
Current: 2 Amps Maximum

FLASH PATTERNS

#	Pattern Name	
1	Quint Flash	Alternating
2	Warp Flash	Alternating
3	Inter-cycle Flash	Alternating
4	Double Flash	Alternating
5	Quad Flash	Alternating
6	3 Flashes / Second	Alternating
7	3 Flashes / Second	Simultaneous
8	Q-Switch	Alternating
9	Driver Side	Steady Burn
	Passenger Side	Road Runner Flash
10	Driver Side	Steady Burn
	Passenger Side	Quint Flash
11	E-Pattern Single Flash	Alternating
12	E-Pattern Double Flash	Alternating
13	E-Pattern Single Flash	Simultaneous
14	E-Pattern Double Flash	Simultaneous
15	Q-Switch	Every other
16	LiteRyder	Slow Sweep
17	LiteRyder 2	Fast Sweep
18	Progressive	Alternating
19	Center	Steady Burn
	Ends	RoadRunner Flash - Alternating
20	Center	Steady Burn
	Ends	Intercycle - Alternating
21	Center	Steady Burn
	Ends	Q-Switch - Alternating